









Instalation manual


ARSAL: STOL 160/210




Element symbol	Dimensions	Code	Package
1	100	STOL_160_210.030	3/3
2	1320	STOL_160_210.031	1/1
3	120	STOL_160_210.032	1/1
4	734	STOL_160_210.034	1/1
5	98	STOL_160_210.035	1/1
6	98	STOL_160_210.036	3/3
7	616	STOL_160_210.037	3/3
8	812	STOL_160_210.027	1/1
9	932	STOL_160_210.028	2/2




3







4



1




2




В РИ С Т О І
 • МАГАЗИН МЕБЛІВ •


7



8



5



6

