











Instalation manual



PAMP: Chest 4S





Element symbol	Dimensions	Code	Package
1	1500 384 16 1	KOM_4S.005	1/1
2	1500 384 16 1	KOM_4S.006	1/1
3	378 384 16 1	KOM_4S.007	1/1
4	378 384 16 1	KOM_4S.008	1/1
5	1466 384 16 1	KOM_4S.009	1/1
6	181 381 16 1	KOM_4S.010	1/1
7	181 381 16 1	KOM_4S.011	1/1
8	202 912 16 1	KOM_4S.012	2/2
9	350 140 16 4	KOM_4S.013	1/1
10	832 140 16 2	KOM_4S.014	1/1
11	350 140 16 4	KOM_4S.015	1/1
12	502 140 16 2	KOM_4S.016	1/1
13	202 912 16 1	KOM_4S.017	2/2
14	198 1484 3 2	KOM_4S.002	1/1
15	846 348 3 2	KOM_4S.003	1/1
16	516 348 3 2	KOM_4S.004	1/1
17	582 202 16 1	KOM_4S.018	2/2
18	582 202 16 1	KOM_4S.019	2/2




1




3




2



4




5








7

! $a=b$



6





ВІСІМЬ МІСЯЦІВ