










Instalation manual

SZAFKA RTV VERNE 2




Element symbol	Dimensions	Code	Package
1	1379	RTV_2S_vagonka.001	1/2
2	1313	RTV_2S_vagonka.002	1/2
3	1313	RTV_2S_vagonka.003	1/2
4	227	RTV_2S_vagonka.004	1/2
5	1313	RTV_2S_vagonka.005	1/2
6	186	RTV_2S_vagonka.006	1/2
7	591	RTV_2S_vagonka.007	1/2
8	400	RTV_2S_vagonka.008	1/2
9	400	RTV_2S_vagonka.009	1/2
10	489	RTV_2S_vagonka.012	1/2
11	489	RTV_2S_vagonka.013	1/2
12	454	RTV_2S_vagonka.014	1/2
13	609	RTV_2S_vagonka.015	1/2
14	652	RTV_2S_vagonka.018	2/2


2x		2x		5x	
2x		1x		40x	
1x		30x		24x	
				30x	
				4x	
				2x	
				10x	
				30x	
				30x	




1




3




2




4




7




8



5





6



9

! a=b



10

