









Instalation manual

SZAFKA RTV 140 INES 2




Element symbol	Dimensions	Code	Package
1	1379 450	RTV_2S_alyzi.001	1/2
2	1313 437	RTV_2S_alyzi.002	1/2
3	1313 437	RTV_2S_alyzi.003	1/2
4	652 220	RTV_2S_alyzi.004	2/2
5	652 220	RTV_2S_alyzi.005	2/2
6	227 415	RTV_2S_alyzi.006	1/2
7	1304 60	RTV_2S_alyzi.007	1/2
8	186 417	RTV_2S_alyzi.008	1/2
9	591 120	RTV_2S_alyzi.009	1/2
10	400 120	RTV_2S_alyzi.010	1/2
11	400 120	RTV_2S_alyzi.011	1/2
12	454 665	RTV_2S_alyzi.018	1/2
13	609 402	RTV_2S_alyzi.021	1/2
14	489 443	RTV_2S_alyzi.016	1/2
15	489 443	RTV_2S_alyzi.017	1/2


2x		φ3x16 mm	p52
2x		L-400	mm
1x		z1	
2x		n260.01.007	n260
1x		y1	
30x		φ8x30 mm	fi
40x		l1	
30x		φ3x12mm f16	r1
30x		s1	
24x		φ3.5x16 mm	p25
10x		φ8x50 mm	e1
10x		c175	
2x		M4x25 mm	j8
2x		s2	
5x		k1	
30x		r16	




1




3




2




4




5




7



6



8



10

9

! a=b

